

SINAMICS V20

Quick launch guide

siemens.com/sinamics-v20



Safety information



For full safety information, please reference the SINAMICS V20 Getting Started Manual (Section 1, pages 1–3).

Technical support information


For technical assistance in your area:

U.S.A.	+1 423 262 5710
Germany	+49 911 895 7222
China	+86 400 810 4288


Additional service contact information:

siemens.com/automation/support-request

Wiring and terminal description




Basic operator panel (BOP)




Dimensions

	Width (mm)		Height (mm)			Depth (mm)	Weight (kg)	Ø	Screw T
Frame size	W1	W2	H1	H2	H3	D	WT approx.		
FSA without fan	79	90	—	140	150	145.5	1	4.6 mm	M4
FSA	79	90	166	140	150	145.5	1.05	4.6 mm	M4
FSB	127	140	160	135	—	164.5	1.8	4.6 mm	M4
FSC	170	184	182	140	—	169	2.6	5.8 mm	M5
FSD	223	240	206.5	166	—	172.5	4.3	5.8 mm	M5

Please refer to Section 2.1 (page 4) of the SINAMICS V20 Getting Started Manual for full dimensions (shown in mm).




Terminal diagram



Recommended fuse types for different frame sizes can be found in Section 2.2 (page 6) of the SINAMICS V20 Getting Started Manual.

Navigation between menus with the M button



Upon power up, the drive defaults to the display menu, Section 3 (page 11) of the SINAMICS V20 Getting Started Manual.

Starting the motor

1. Power up the drive
 2. Set to factory default
 3. Enter motor data
 4. Select connection macros
 5. Select application macro
 6. Set general parameter settings
 7. Start motor
- Cn000** — No chosen connection macro
Cn001 — BOP as the only control source
Cn002 — Control from terminals (PNP / NPN)
Cn003 — Fixed speeds
Cn004 — Fixed speeds in binary mode
Cn005 — Analog input and fixed frequency
Cn006 — External push button control
Cn007 — External push buttons with analog control
Cn008 — PID control with analog reference
Cn009 — PID control with the fixed value reference
Cn010 — USS control
Cn011 — MODBUS RTU control

Connection macro wiring diagrams found in the SINAMICS V20 Getting Started Manual (section 3.2.2, page 13)

Connection macros are fixed and cannot be modified. If your setup requires different parameters, select Ch000 to set parameters manually


Application macro and factory default settings are found in the SINAMICS V20 Getting Started Manual (section 3.2.3, page 16)

Common parameter descriptions can be found in the SINAMICS V20 Getting Started Manual (section 3.2.4, page 16)

Connection macro wiring diagram

Cn002 — Control from terminals (PNP / NPN):

- external control
- potentiometer with setpoint
- Hand/auto switch between the BOP and terminals by pressing **M** + **OK**



SINAMICS V20 programming example

The example below walks through a quick commissioning for a basic conveyor application (AP030) that is controlled by the BOP using the connection Cn001. The motor will be set to have a minimum frequency of 5 Hz and is characterized by the following:

Enter relevant motor data in the underlined sections and highlighted boxes below:
 Voltage: _____ ex: 400 V Power: _____ ex: 0.37 kW Freq.: _____ ex: 50/60 Hz
 Current: _____ ex: 1.10 A Eff.: _____ ex: 70% Motor RPM: _____ ex: 1500 RPM

Step	Current display value	Press button	New display value	Press button	Comments
1	Power up drive				Starting from display menu
2	Set to factory default				
2.1	Any	M < 2 s			Switches to the parameter menu
2.2	Any	▲ or ▼	P0010	OK	
2.3	0	▲	30	OK	Commissioning parameters → factory reset
2.4	P0010	▲	P0970	OK	
2.5	0	▲	21	OK	Activates factory reset
3	Enter motor data				
3.1	50?	OK		OK	Set P0100 = 0, motor type IEC, kW
3.2	P0304	OK		OK	
3.3	460	▲ or ▼		OK	P0304 — Motor voltage
3.4	P304	▲	P0305	OK	
3.5	1.10	▲ or ▼		OK	P0305 — Motor current
3.6	P0305	▲	P0307	OK	
3.7	0.50	▲ or ▼		OK	P0307 — Motor Hp
3.8	P0307	▲	P0309	OK	
3.9	0.7	▲ or ▼		OK	P0309 — Motor efficiency
3.10	P0309	▲	P0310	OK	
3.11	60.00	▲ or ▼		OK	P0310 — Motor Hz.
3.12	P0310	▲	P0311	OK	
3.13	1750	▲ or ▼		OK	P0311 — Motor RPM
3.14	P0311	▲	P1900	OK	
3.15	0	▲	2	OK	Activate motor ID tune
Alarm icon appears on screen					
4	Select connection macro				
4.1	P1900	M < 2 s			
4.2	-Cn000	▲	Cn001	OK	Select connection macro 1
4.3	-Cn001	M < 2 s			
5	Select application macro				
5.1	-AP000	▲	AP030	OK	Select application macro 30
5.2	-AP030	M < 2 s			
88888 briefly fills the display				Drive processing internal data	
6	Set general parameter settings				
6.1	P1080	OK			
6.2	20.00	▼	5.0	OK	Lower minimum frequency
6.3	P1080	M > 2 s			Exit quick commissioning
7	Start motor				

Troubleshooting

Common fault acknowledgement

Fault code list

Fault	Description	Fault	Description
F1	Overcurrent	F62	Parameter cloning contents invalid
F2	Overvoltage	F63	Parameter cloning contents incompatible
F3	Undervoltage	F64	Drive attempted to do an automatic clone during startup
F4	Drive overtemperature	F71	USS setpoint fault
F5	Drive I ² t	F72	USS / MODBUS setpoint fault
F6	Chip temperature rise exceeds critical levels	F80	AI lost input signal
F11	Motor overtemperature	F85	External fault
F12	Drive temperature signal lost	F100	Watchdog reset
F20	DC ripple too high	F101	Stack overflow
F35	Auto restart after n	F221	PID feedback below minimum value
F41	Motor data identification failure	F222	PID feedback above maximum value
F51	Parameter EEPROM fault	F350	Configuration vector for the drive failed
F52	Drive software fault	F395	Acceptance test / confirmation pending
F60	ASIC timeout	F410	Cavitation protection failure
F61	MMC / SD card parameter cloning failed	F452	Belt failure

- To navigate through the current list of faults, press **▲** or **▼**
- To clear / acknowledge the fault, press **OK** or acknowledge externally if the drive has been setup so
- To ignore the fault, press **M**
- After you acknowledge or ignore the fault, the screen returns to the previous display. The fault icon remains active until the fault is cleared / acknowledged

Setting common parameters

Parameter	Description	Parameter	Description
P1080[0]	Minimum motor frequency	P1001[0]	Fixed frequency setpoint 1
P1082[0]	Maximum motor frequency	P1002[0]	Fixed frequency setpoint 2
P1120[0]	Ramp-up time	P1003[0]	Fixed frequency setpoint 3
P1121[0]	Ramp-down time	P2201[0]	Skip frequency setpoint 1
P1058[0]	JOG frequency	P2202[0]	Skip frequency setpoint 2
P1060[0]	JOG ramp-up time	P2203[0]	Skip frequency setpoint 3